

REFEX pH electrode hard wiring to Yokogawa pH to EXA PH202 meter

Wiring Connections:

CLEAR wire on REFEX Electrode	Terminal # 15 on Yokogawa EXA PH202 pH Meter
COPPER BRAID on REFEX Electrode	Terminal # 16 on meter
GREEN wire on REFEX Electrode	Terminal # 13 on meter
BLUE wire on REFEX Electrode	Terminal # 14 on meter
RED wire on REFEX Electrode	Terminal # 11 on meter
WHITE wire on REFEX Electrode	Terminal # 12 on meter

Place Jumper in **LOW IMP** Terminals on **INPUT 2**

TO CHANGE IMPEDANCE FROM LOW TO HIGH ON REFERENCE INPUT

Enter - **SERVICE - YES**

Enter - **CODE - 04**

Change setting on **INPUT Z2.CHK** to **0.1.0**

