

# REFEX pH electrode hard wiring to ABB APA 592 pH meter

## Wiring Connections:

- CLEAR** Wire on REFEX Electrode - Terminal # 4
- GREEN** Wire on REFEX Electrode - Terminal # 6
- BLUE** Wire on REFEX Electrode - Terminal # 7
- COPPER BRAID** on REFEX Electrode - Terminal # 5
- RED** Wire on REFEX Electrode - Terminal # 8
- WHITE** Wire on REFEX Electrode - Terminal # 9
- PLACE JUMPER BETWEEN TERMINAL # 9 AND TERMINAL # 11**

