

# REFEX pH electrode hard wiring to KNICK ECO 2405 pH meter

## Wiring Connections:

- CLEAR** wire on Refex Electrode – Terminal # 1
- GREEN** wire on Refex Electrode – Terminal # 2
- BLUE** wire on Refex Electrode – Terminal # 3
- COPPER BRAID** wire on Refex Electrode – Terminal C
- RED** wire on Refex Electrode – Terminal – D
- WHITE** wire on Refex Electrode – Terminal – E
- ESD SHIELD MUST BE RE-FITTED OVER CONNECTION BLOCKS**

