

REFEX pH electrode hard wiring to Rosemount 5081 Explosion - proof transmitter

Wiring Connections:

CLEAR wire on REFEX Electrode	Terminal # 10 on Rosemount 5081 ph meter
COPPER BRAID wire on REFEX Electrode	Terminal # 9 on meter
GREEN wire on REFEX Electrode	Terminal # 7 on meter
BLUE wire on REFEX Electrode	Terminal # 8 on meter
RED wire on REFEX Electrode	Terminal # 5 on meter
WHITE wire on REFEX Electrode	Terminal # 3 on meter
JUMPER MUST BE FITTED BETWEEN TERMINALS 3 AND 4	

